

Pre-sewn Chafe Installation Instructions

1. Use the enclosed needle to tie “whipping twine” to end of line.
2. Allow thread and needle to pass through pre-sewn chafe leather.
3. Pull line through chafe leather
4. Position chafe on line.
5. Whip ends of chafe leather to line to hold in position.

BOAT LEATHER

3050 38TH AVENUE WEST

SEATTLE, WA 98199

(206) 284-9110 www.boatleather.com